



**Full wave CT:**

Connect all three transformer wires  
Install D1 and D2 ONLY

**Full wave bridge:**

Do NOT connect transformer CT  
Install all rectifier diodes

**Full wave tube:**

Connect transformer CT ONLY  
Short D1  
Do not install D2 - D4  
Connect tube cathode to T1

**Hybrid tube bridge:**

Do NOT connect transformer CT  
Short D1  
Install D3 and D4 ONLY  
Connect tube cathode to T1

**Recommended diodes:**

CREE CSD1060A  
CREE C3D02060F or CSD2060A

**Recommended capacitors:**

100uF 450V: Nichicon LGU2W101MELA  
47uF 450V: Nichicon LGU2W470MELY

Use 47uF at C1 if using tube rectifier

Use 47uF at C1 and C2 if output current < 50mA

**MEC power supply**  
www.pmilllett.com

TITLE: hvrect\_mec

Document Number:

REV:

Date: 7/10/2018 2:06 PM

Sheet: 1/1